



*L'atelier de Bois
Exotique*

(514) 893-6507
www.bois-exotique.com



Steps to finish with Tung oil:

1. Mix the contents well before and during application. Apply without diluting.
2. Apply a layer of Tung oil with a non-fluffy cloth, foam brush or tampon.
3. Allow the oil to penetrate for about 3-5 minutes. If there are places that become dry before the end of 3-5 minutes, simply add more.
4. At the end of 5 minutes, wipe off any excess with a clean cloth.
5. If the oil continues to rise to the surface after being wiped, continue to wipe every 10 minutes until the oil does not return.
6. Allow to dry for 24 hours.
7. When the citronella scent is dissipated, the Tung oil should be catalyzed (dry).
8. To smooth the surface (if necessary) between the layers, sand with a steel wool (0000). Wipe the surface to remove dust or other materials.
9. Apply a second thin layer and immediately remove any excess.
10. For a slightly brighter finish, a third and fourth thin layer can be applied. Wait 24 hours between coats.
11. Wait 7 days before using a product other than Tung oil (such as varnish, urethanes, waxes or others) as an additional protective layer.

Steps for finishing with "Minwax" Wipe on poly:

1. Shake the container before use.
2. Mix content well before and during application. Apply without diluting.
3. Apply a thin layer of urethane with a non-fluffy cloth or tampon. Do not apply with a paintbrush as this will leave too thick a coat.
4. Allow to dry for at least 2 to 3 hours.
5. Before applying another layer, lightly sand the entire surface (if necessary) with steel wool (0000). Remove all sanding dust.
6. Apply a second coat in the same way as for the first. If you want to apply a third coat, repeat step 5 before application.
7. Allow the final coat to dry 24 hours before normal use.